

MAKER : SONY

INF.	DEVICE NAME DEVICE DISPLAY	PACKAGE GROUP	SIZE(bit) Other	Vpp(V)	TR4943			R4944A			R4945/A			R4952		TR4948		R4951		R4953		R4932 PR493200		
					CODE Rev	CODE Rev	Adapter	CODE Rev	Adapter ID	DB	ASSY	CODE Rev	Adapter ID	CODE Rev	Adapter Rev	CODE Rev	Adapter ID	CODE Rev	Adapter ID	CODE Rev	Adapter ID	DB		
	CXK27C256DQ CXK27C256	DIP-28 EPROM	256K(*8) UVE	12.75				E1054E D00	R49451A DB		E1054E D00	R49512B D00		R49512B D00	E1054E D00	R49531A D00								
	CXK27C512DQ CXK27C512	DIP-28 EPROM	512K(*8) UVE	12.75				E1054F D00	R49451A DB		E1054F D00	R49512B D00		R49512B D00	E1054F D00	R49531A D00								
	CXK27C1000DQ CXK27C1000	DIP-32 EPROM	1M(*8) UVE	12.75				E10550 D00	R49451A DB		E10550 D00	R49512B D00		R49512B D00	E10550 D00	R49531A D00	E10550 D00	R49531A D00	E10550 D00	R49321A D00				
	CXK27C1001DQ CXK27C1001	DIP-32 EPROM	1M(*8) UVE	12.75				E11550 D00	R49451A DB		E11550 D00	R49512B D00		R49512B D00	E11550 D00	R49531A D00	E11550 D00	R49531A D00	E11550 D00	R49321A D00				
	CXK27C2001DQ CXK27C2001	DIP-32 EPROM	2M(*8) UVE	12.75				E11551 G00	R49451A DB		E11551 D00	R49512B D00			E11551 D00	R49531A D00	E11551 D00	R49531A D00	E11551 D00	R49321A D00				
	CXK27C4001DQ CXK27C4001	DIP-32 EPROM	4M(*8) UVE	12.75				E11552 G00	R49451A DB		E11552 D00	R49512B D00			E11552 D00	R49531A D00	E11552 D00	R49531A D00	E11552 D00	R49321A D00				
	CXK27C4002DQ CXK27C4002	DIP-40 EPROM	4M(*16) UVE	12.75				E10572 G00	R49451A DB		E10572 D00	R49513B D00					E10572 D00	R49531A D00	E10572 D00	R49321A D00				